

FOOD HOSE CLEANING

1. WATER / STEAM :

CITERDIAL - ALCODIAL - DISTRIVIN Hot water 70°C to 90°C
Steam at 110°C **10 minutes maximum**

ALIKLER - ALIKLER D
MILLESIME - TRELLVIN Hot water 70°C to 95°C or
BIOVAST / KLENET Steam at 130°C (**165°C for BIOVAST**)

2. CHEMICAL CLEANING :

**CITERDIAL - ALCODIAL - ALIKLER - ALIKLER D - MILLESIME - DISTRIVIN -
TRELLVIN - KLENET - BIOVAST**

Oxidizing acid :

Nitric acid (**HNO₃**) or product with additional nitric acid

Maximum concentration **HNO₃** 0,1 % at 85°C
3 % **at room temperature.**

Alkaline cleaning product :

Alkaline liquid soap ,caustic sodium , potassium hydroxide

Maximum concentration **NAOH** 2% 60°C to 80°C
5% at **Maximum 40°C**